

## PSG Plus Probe DeNOx

### **Application**


The heated gas sampling probes of the **PSG Plus Probe DeNOX** series are used for continuous extractive gas analysis. They are used for the trouble-free representative sampling of hot heavily dust and water vapour loaded gases. Typical applications are DeNOx processes (SCR) in which  $NH_3$  is added to the flue gas to reduce the NOx content.

### Technology

The **PSG Plus Probe DeNOx** probes are based on the PSG Plus probe series. With the market's largest filtration surface of 212 cm<sup>2</sup> and the dual stage back purging with 12x1 mm tubing, which is controlled via two Coax solenoid valves with 10 mm passage, this enables operation in high dust concentrations of up to 280 g/m<sup>3</sup>. In combination with the full-surface, close-fitting heating sleeve and the thick-walled glass-fibre insulating jacket, which enables homogeneous heating of the **PSG Plus Probe DeNOx** to 180°C, dust is reliably separated without condensation of water vapour and therefore without blocking of the filter. The membrane coated ceramic filter with 0,3  $\mu$ m porosity additionally supports the great back purge effectiveness.

For use in DeNOx processes, the **PSG Plus Probe DeNOx** is also equipped with a glass condensate vessel. This is filled with glass balls to increase the surface for the saltification. The condensate with dissolved ammonium salts is removed via the built-in peristaltic pump type SR25. Due to the hot gas flow, the temperature of the condensate vessel is higher than the ambient temperature. In order to determine the loss of measuring components, the **PSG Plus Probe DeNOx** is equipped with a test gas inlet including piping. The built-in protection against accidental contact ensures safety.

Thanks to the intelligent design, both the filter change and the maintenance of the separating vessel can be carried out quickly and without tools.



- Largest active filter surface on the market
- Dual stage back purging with 10 mm passage
- Corrosion resistant made of stainless steel SS316Ti
- Controlled heating to 180°C
- Comfortable maintenance without tools
- Separator with glass ball filling
- Peristaltic pump for condensate drainage
- Test gas connection as standard
- Protective housing for outdoor installation




# **Technical Data**

Process gas sampling conditions PSG Plus	Probe DeNOx
Pressure	p <sub>abs</sub> = 50600 kPa
Temperature	max. 200°C at probe inlet
Flow	30…1500 l/h, referred to 100 kPa and 0°C
Pressure drop	approx. 0,6 hPa at 100 l/h
Max. dust concentration	280 g/m <sup>3</sup>
Connections	
Sample gas outlet / Condensate outlet	Hose screw connection DN4/6
Test gas / Tubing	G1/4" f (DIN ISO 228/1) / 6mm tube
Back purge / Tubing	12x1mm tube
Heating	
Туре	Heating sleeve incl. PT100, 250W (350W optional)
Insulation	Removable insulation jacket
Temperature	180°C (315°C with 350W option)
Temperature alarm	approx. 150°C
	PID-controller ST49 incl. solid state relay for DIN-rail-mounting
Temperature control	Thermostat control with controller in connection box
Filter properies PSG Plus	
Filter	Surface filter, ceramic coated
Porosity	0,3 µm
Tightness	10 <sup>-4</sup> hPa l/s
Dead volume	
	approx. 280 ml
Dimensions	50/20 x 135 mm
Protective Housing	
Dimension	330 x 205 x 270 mm (L x B x T)
Material	Stainless steel SS 304
Ambient temperature	-20°C +60°C
Weight	approx.31 kg (complete probe)
Drotaction class connection box	IP65 EN 60529
Protection class connection box	1F03 EN 00323
Mountin	
Mountin Flange	DN 65, PN 6, 4-hole, form B according to DIN 2527
Mountin Flange Installation angle	
Mountin   Flange Installation angle   Materials in contact with sample gas	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended)
Mountin Flange Installation angle	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti
Mountin   Flange Installation angle   Materials in contact with sample gas	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional)
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional)
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump   Part Numbers   53402211	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump   Part Numbers   53402207	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump   Part Numbers   53402207   53500098	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump   Part Numbers   53402211   53500098   Spare part numbers	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC   2/2-Way pneumatic valve installed in sample gas path (Optional)
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump   Part Numbers   53402211   53500098   Spare part numbers   80060176	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC 2/2-Way pneumatic valve installed in sample gas path (Optional) Ceramic filter coated 0,3 µm incl. 2 filter element gaskets
Mountin   Flange   Installation angle   Materials in contact with sample gas   Housing, flange, gas connections   Gaskets   DeNOx separator vessel   Vessel / Filling   Volume   Filling level   Quantity of glass balls in Vessel (Ø10 mm)   Peristaltic pump   Part Numbers   53402211   53500098   Spare part numbers   80060176   80060638	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC 2/2-Way pneumatic valve installed in sample gas path (Optional) Ceramic filter coated 0,3 µm incl. 2 filter element gaskets O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers8006017680060740	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC 2/2-Way pneumatic valve installed in sample gas path (Optional) Ceramic filter coated 0,3 µm incl. 2 filter element gaskets O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element) Separator vessel Duran®-Glass (incl. 1 KG glass balls)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers80060176800606388006074030114513	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC 2/2-Way pneumatic valve installed in sample gas path (Optional) Ceramic filter coated 0,3 µm incl. 2 filter element gaskets O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element) Separator vessel Duran®-Glass (incl. 1 KG glass balls) GL hose screw connection for hose with DN4/6 (for separator vessel)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers80060176800607403011451380060741	DN 65, PN 6, 4-hole, form B according to DIN 2527 10°-35° inclination to horizontal position (recommended) Stainless steel SS 316Ti FPM (FFKM optional) FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging) Duran®-Glass / Glass balls (Ø10 mm) 330 ml 150 mm 500 g SR25 PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC 2/2-Way pneumatic valve installed in sample gas path (Optional) Ceramic filter coated 0,3 µm incl. 2 filter element gaskets 0-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element) Separator vessel Duran®-Glass (incl. 1 KG glass balls) GL hose screw connection for hose with DN4/6 (for separator vessel)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers8006017680060740301145138006074180060743	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC   2/2-Way pneumatic valve installed in sample gas path (Optional)   Ceramic filter coated 0,3 µm incl. 2 filter element gaskets   O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element)   Separator vessel Duran®-Glass (incl. 1 KG glass balls)   GL hose screw connection for hose with DN4/6 (for separator vessel)   Quick release ring DN60 (for separator vessel)   Gasket for quick release ring (for separator vessel)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers800601768006074030114513800607418006074330008695	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC   2/2-Way pneumatic valve installed in sample gas path (Optional)   Ceramic filter coated 0,3 µm incl. 2 filter element gaskets   O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element)   Separator vessel Duran®-Glass (incl. 1 KG glass balls)   GL hose screw connection for hose with DN4/6 (for separator vessel)   Quick release ring DN60 (for separator vessel)   Glass balls Ø10 mm (1 KG)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers80060176800607403011451380060741800607433000869592300498	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC   2/2-Way pneumatic valve installed in sample gas path (Optional)   Ceramic filter coated 0,3 µm incl. 2 filter element gaskets   O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element)   Separator vessel Duran@-Glass (incl. 1 KG glass balls)   GL hose screw connection for hose with DN4/6 (for separator vessel)   Quick release ring DN60 (for separator vessel)   Glass balls Ø10 mm (1 KG)   Hose set N3,2x1,6mm with bolted joint – 210ml/h (for SR25)
MountinFlangeInstallation angleMaterials in contact with sample gasHousing, flange, gas connectionsGasketsDeNOx separator vesselVessel / FillingVolumeFilling levelQuantity of glass balls in Vessel (Ø10 mm)Peristaltic pumpPart Numbers5340220753500098Spare part numbers800601768006074030114513800607418006074330008695	DN 65, PN 6, 4-hole, form B according to DIN 2527   10°-35° inclination to horizontal position (recommended)   Stainless steel SS 316Ti   FPM (FFKM optional)   FFKM instead of FPM for heating to 315°C or corrosion resistant version (with back purging)   Duran®-Glass / Glass balls (Ø10 mm)   330 ml   150 mm   500 g   SR25   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 230V AC   PSG Plus DeNOx, 250 W 230 V 50/60 Hz, with thermostat controller in connection box, Solenoid valves in 24V DC   2/2-Way pneumatic valve installed in sample gas path (Optional)   Ceramic filter coated 0,3 µm incl. 2 filter element gaskets   O-ring-set FFKM for probes with back purging (2 x lid + 2 x filter element)   Separator vessel Duran®-Glass (incl. 1 KG glass balls)   GL hose screw connection for hose with DN4/6 (for separator vessel)   Quick release ring DN60 (for separator vessel)   Glass balls Ø10 mm (1 KG)



### **PSG Plus Filter**

#### Dimensions



Dimessions in mm





State 07 / 2022 | Subject to change